



950WS Wall Sensor Mounting Instructions

FLAT WALL INSTALLATION


1. Bend bracket at locations marked (A) and (B) so that back section (C) of bracket is at approximately a 90° angle with bottom section (D) and front section (E) is angled downward as shown.



2. Mount bracket to wall using appropriate wall anchors (for wall type) through holes in back section (C).




3. Slide wall sensor onto front section (E). Adjust bend (B) in bracket so that so that sensor will face the center of its "zone" (see receiver installer guide)



INSIDE CORNER INSTALLATION


1. Bend bracket at locations marked (A) and (B) so that sides (C) are at approximately 45° angles with back section (D) as shown



2. Mount bracket to wall using appropriate wall anchors (for wall type) through holes in back section (C).



3. Bend bracket at locations marked (E) and (F) so that back section (G) of bracket is at approximately a 90° angle with bottom section (H) and front section (I) is angled downward as shown.



4. Slide wall sensor onto front section (I). Adjust bend (F) in bracket so that so that sensor will face the center of its "zone" (see receiver installer guide)

