

Microphone Registration

READ ME FIRST!

You **must** register (pair) microphones before first use.

- **1. Charge Microphones** Place mics in the charger until Battery LED is slowly pulsing green.
- **2.** Activate Base Station Press the Mic Registration button on the ELEVATE Base Station (or remotely via the CM900 Web Page). The ClassLight will flash green.
- 3. Activate Mic
 - Remove mic from charger, and wait until it wakes up (8 seconds then double-beep)
 - Press the Mute button for 4 seconds until you hear a triple-beep, then let go. Both LEDs will flash green.
- **4. Ready!** Registration takes a few seconds. When complete, the ClassLight will stop flashing and the mic will beep again. The mic is now ready for use.
- 5. Repeat steps 2-4 for additional mics, or when moving a mic to another room.

See the User Guide for more information. www.gofrontrow.com/elevate-help





Scan for complete User and Install Guide



www.gofrontrow.com/elevate-help