

ATTENTION: INSTALLER

Microphones **must** be registered to this system in order to work:

1. Press the Mic Registration button on the ELEVATE Base Station.
The ClassLight will flash light blue.
2. Insert mic into charger, wait until it wakes up, then remove.
3. Press and hold the Mute (rectangle) button on the Mic until you hear the double-beep (about 2 seconds) then release. Both LEDs will flash GREEN.
(If the mic does not enter registration mode, then it is already registered with a nearby Base Station.)
4. After a few seconds the mic will beep and be registered with this Base Station.

See the **User Guide** for more information.

www.gofrontrow.com/elevate-help



Scan for complete User and
Install Guide



www.gofrontrow.com/elevate-help

1530-00075/RevB 0222