




Juno Quick Start Guide

Juno Quick Start


With Juno, every student gets a FrontRow seat! Elevating the teacher's voice is one of the easiest and most powerful actions you can take to improve student performance while helping teachers manage classrooms and avoid vocal strain and fatigue.

1. Mount the Juno on a wall (VESA mount sold separately) or place on a shelf high enough where students can see it.


Top View




Side View



2. Plug the power supply into the back and turn on the Juno.




3. Place the Teacher mic around neck. Press the single button to wake the mic.




4. Adjust the volume using the master volume on the Juno main screen.



5. **Optional:** Go to your Bluetooth® settings on your phone, then Press the Bluetooth button on the back of the Juno to pair your phone.



6. **Optional:** Connect the Class2Home cable kit to the Juno and connect the USB cable to your computer to use Juno for video conferencing and hybrid learning.



7. Get the latest Juno Installation, Setup, and User Guides, as well as desktop software to change microphone and tower configuration settings:
<https://www.gofrontrow.com/support/download-centers/juno/>

