

Cleaning Instructions for FrontRow Products

This document provides guidelines for cleaning and disinfecting FrontRow products as it relates to COVID-19. Using or sharing hand-held or body-worn products or touching products exposed to multiple people may create a risk of transferring virus particles from one user to another.

Even apparently healthy individuals could have an unrecognized coronavirus condition. Cleaning and disinfection of FrontRow products is strongly recommended, especially products that are shared between users.

The following guidelines apply to FrontRow Juno, ezRoom, Pro Digital and ToGo systems.

- Wear gloves when cleaning FrontRow products.
- Most types of commercially available cleaners and disinfectants can be used on FrontRow microphones, transmitters, receivers and control panels.
- Water-based disinfectants are optimal. A solution of 70% isopropanol may also be used. Never apply hand sanitizers on FrontRow products.
- Wipe the entire surface of a unit with the damp disinfectant wipe/towel.
- Take care to avoid directly touching microphone openings with excess liquid. Damp wipe is best.
- After cleaning, discard the used gloves and wipes/towel, and wash your hands carefully with soap and water or disinfect with a suitable alcohol disinfectant.
- Let the unit dry for a couple of minutes.



PRODUCTS TO CLEAN AND DISINFECT



Juno Tower



Teacher Microphone



Student Microphone



ToGo Tower



ToGo Transmitter



ToGo Handheld Microphone



ProDigital Receiver



ezRoom CB6000 Control Panel



ezRoom CB2050 Control Panel