



Summer Storage Tips for Sound Field

As the school year comes to a close, many of you have questions regarding summer storage of your sound field systems (infrared, FM installed and the FM portable systems). Basically, summer storage is pretty simple:

1) Disconnect the receiver box, and store with transformer plug in a dry area for the summer. The speakers and wiring can stay put in the class. In the case of the portable system, please store the speaker/receiver for the summer in a cool, dry place that is away from all sources of heat.

2) Take the batteries out of the transmitter, and store in a bag with transmitter, microphone, and charger plug with the receiver in that same dry area. Whether you'd like to have all the systems in the same place, or each system stored in its respective classroom is up to you. Taking the batteries out of the transmitter is the most important factor in summer storage, give those batteries a rest!

When returning from break, the FrontRow ToGo may not charge to its full potential and last the full eight hours. In order to rectify this condition you will need to charge and use the unit several times. This condition may also be seen in other units that use NiMH batteries, which includes body pack transmitters and pendant microphone.

If you have any further questions please call 1-800-227-0735 ext 5 for service, or get online assistance at www.gofrontrow.com.

Thanks for your business and have a wonderful summer break!