

The Lyrik Video Cable Kit includes two 3.5mm to 3.5mm audio cables (3.66m/12ft) and a USB audio stereo adapter, enabling audio to and from the Teacher's computer for capturing Lessons, or for use with video conferencing software such as Zoom™, Teams™, and Google Meet™.



## Connect Lyrik Tower to Teacher's computer

1. Using the first 3.5mm cable, connect the **AUX AUDIO Out** to the **PINK** input on the USB adapter.
2. Using the second 3.5mm cable, connect the **AUX AUDIO In** to the **GREEN** input on the USB adapter.
3. Plug the USB adapter into the computer.
4. On your computer, set your sound settings or video conferencing software to "C-Media USB" for input/microphone and output/headphones/speakers.

