

# ToGo Quick Start Guide

**Step 1: Set up Receiver**

- Connect antenna
- Open and screw in table stand
- Connect power cord
- Turn main power on

**Step 2: Set up Transmitter and Charger**

- Insert batteries into transmitter
- Connect power cord to charger
- Place transmitter in charger and charge overnight
- Note: red "charging" light on charger should be on

**Step 3: Match Transmitter and Receiver Channel Numbers**

You can use two transmitters simultaneously with your ToGo system as the receiver has two receiving channels, A and B.

- Match the channel number on the first transmitter to the Channel A channel number on the receiver (e.g., 41)
- Match the channel number on the second transmitter to the Channel B channel number on the receiver (e.g., 51)

**Step 4: Turn on Transmitter**

- Connect microphone to transmitter
- Turn on transmitter

**Step 5: Turn on Receiver**

- Turn receiver Channel A or B on and adjust volume


**Step 6: OptiVoice<sup>™</sup>**


- Low: use in low noise environments for the most natural voice reproduction
- Mid: use in moderately noisy environments to increase emphasis on mid and high speech frequencies
- High: use in noisy environments to optimize mid and high speech frequencies for maximum speech intelligibility

**Step 7: Connect CMBT Bluetooth<sup>®</sup> Audio Receiver**

Optional

- Attach the supplied rubber feet to the bottom of the CMBT receiver and select a stable space near the 925RS
- Connect the supplied power source to the 5VDC jack of the CMBT and plug the supply into an electrical outlet
- Plug one of the supplied 3.5mm audio cables into the **Bluetooth Audio Out** jack on the CMBT and connect the other end to one of the available audio inputs on the 925RS.





- |  |                              |
|--|------------------------------|
| ① Table Stand                                      | ⑦ Pass Microphone (optional) |
| ② Power Cord                                       | ⑧ Behind the Neck Boom Mic   |
| ③ Charger for Transmitter                          | ⑨ Wall Bracket with Screws   |
| ④ Auxiliary Input Cord Kit<br>(DVD/Computer Sound) | ⑩ Body Worn Transmitter      |
| ⑤ Antenna  | ⑪ Carry Case (optional)      |
| ⑥ Receiver & Speaker Column                        | ⑫ Volume Locks               |

#### FrontRow USA/Global

1690 Corporate Circle  
Petaluma, CA 94954  
tel: 800.227.0735  
fax: 707.769.9624  
gofrontrow.com

#### FrontRow Canada

6950 Creditview Rd, Unit 1  
Mississauga, ON L5N 0A6  
tel: 800.340.9894  
fax: 905.677.7760  
gofrontrow.com

#### FrontRow Australia

629 Nudgee Road  
Nundah Qld 4012  
tel: 1800 746 642  
fax: 1300 737 983  
gofrontrow.com

#### FrontRow Nordic

Phonic Ear A/S  
Kongebakken 9  
DK-2765 Smørum  
tel: +45 3917 7101  
phonicear.dk

#### FrontRow UK

Cadzow Industrial Estate  
Low Waters Road  
Hamilton  
Lanarkshire ML37QE  
tel: +44 (0) 1698 208268