


Surface Mount Enclosure Wall-mounting Instructions

IMPORTANT INFORMATION

1. Use appropriate wall-mount fasteners for the intended wall surface (see *Image 1*). If fastening into studs, use the appropriate screws for the type of stud (metal or wood).


Image 1



NOTE: If the recommended fasteners cannot be used, any alternate fastener must be rated to support 60 lbs or more.

2. The 2" by 3.5" opening in the bottom left corner of the tray should fit over a standard duplex outlet after installation (see #1 in *Image 2*).
3. The 2.75" by 2.75" opening in the bottom right corner is where the signal lines coming from the wire raceways will be routed through (see #2 in *Image 2*).


Image 2



MOUNTING INSTRUCTIONS

1. Place Tray-Mounting Template (1530-00030) on the wall where the unit is to be installed, making sure that the lower left opening is placed over a duplex receptacle, and that the signal wire raceways are aligned to enter behind the unit from the top or bottom (see *Image 3*).
2. Mark the locations of the mounting holes on the wall.
3. Install the appropriate wall anchors, if not fastening into studs.
4. Insert the top 2 screws, leaving the screw heads exposed by approximately 2mm (5/64").
5. Run the signal wires through the opening and place the keyhole openings in the top of the tray over the screw heads and lower into place.
6. Insert 2 screws into the 2 lower mounting holes and tighten.
7. Tighten the screws in the keyhole mounting slots.

Image 3



frontrow™